



PARTS CATALOGUE
MODEL YEAR 2000
TW200M (5FY5) U49
TW200MC (5FY6) CALIFORNIA

STARTING VIN	(5FY5):	JYA3AWE0*YA081335
	(5FY6):	JYA3AWC0*YA081335

Color Code	Color Name	Abbreviation
035	SILVER	SL
206	PURPLISH WHITE SOLID 1	PWS1

OWNERS **LIT-11626-13-17**
ASSEMBLY **LIT-11666-05-93**
SERVICE **LIT-11616-06-26**

FOREWORD

-INTRODUCTION-

To The Yamaha Parts Fiche

This parts fiche lists parts and sub-assemblies for the TW200M/MC. When preparing a parts order, please refer to the most recently updated microfiche for this model.

THE YAMAHA PARTS FICHE

SYMBOLS

I	Inactive, no longer available
J	Use size (thickness) and/or number as required
U.N.	Use as many as you need
T	Number of teeth in a gear
V	Voltage for light bulbs
S	"S" type oil seal or "S" type circlip
SD,SO,SW	"SD", "SO", or "SW" type oil seal
E,R	"E" or "R" type circlip
F/No.	Frame No. (Applicable Machine No.)
L.M.	Locally made
O.L.	Obtain locally
AP	Alternate Part

SUPERSEDED PART NUMBERS

If part 'A' has been superseded by part 'B', the superseding part number "B" will appear in the part number listing with the superseded part number "A" appearing in parentheses immediately following the description.

EXAMPLE:

Ref. No.	Part No.	Description	Qty.
	(Part 'B')	(Part 'A')	
8	123-45678-00-00	CYLINDER (111-12345-00-00)	1

A part that has been supersede to a kit may be identified by a 99999-00000-00 part number appearing in the part number column. The old superseded part number will appear in parentheses immediately following the description. Listed directly below the 99999 part number will be those parts making up the kit. The description of the parts making up the kit will be preceded by a small black dot (.) and the description will be indented one letter space.

EXAMPLE:

Ref. No.	Part No.	Description	Qty.
8	99999-12345-00	CYLINDER (111-12345-00-00)	1
	234-56789-00-00	• HEAD, CYLINDER	1

SIZES

Except for steel balls (ball sizes are indicated in inches), all parts sizes are indicated in millimeters as in the following examples:

Hose (Rubber or Vinyl)Inside Diameter - Length

O-Ring Section Area - Inside Diameter

Washer, Shim, Collar.....Inside Diameter - Outside Diameter
Thickness (Length)

ASSEMBLIES AND COMPONENT PARTS

Assemblies and their component parts, are identified by an indentation of one letter space, and the description is preceded by a dot (.). If two main assemblies are listed, and have the same basic description (i.e.: left and right sides of the same assembly), one will immediately follow the other. If each of these main assemblies is made up of almost the same components, these component parts will be listed immediately under the second main assembly line and will be indicated, as noted above.


If the component is the same for both main assemblies, the quantity indicated will be the total required. If the component is not the same for both main assemblies, the quantity for each separate item will be listed separately.

EXAMPLE:


Description	Qty
CARBURETOR ASSY, LEFT	1
CARBURETOR ASSY, RIGHT	1
. JET, PILOT	2
. NOZZLE, MAIN	2
. LEVER, STARTER, LEFT	1
. LEVER, STARTER, RIGHT	1

APPLICABLE SERIAL NO.

(1) Engine Serial No.



(2) Frame Serial No.




FOREWORD

THE YAMAHA PART NUMBER

The Yamaha part number consists of 12 digits. Each number represents a specific piece of information relating to a replacement part. The following is a guide for reading and interpreting the Yamaha part number.

BASIC PART NUMBER CONFIGURATION:



MODEL CODE NUMBER

FIRST THREE DIGITS . . . 000-00000-00-00


Every model in each Yamaha product line is assigned a model number to identify that particular model. All component parts are given the model code number relating to the model on which they were first used.

Example: 4DU-00000-00-00 identifies the XJ600SE.
3FA-00000-00-00 identifies the YFA1E.

BASIC CODE NUMBER


MIDDLE FIVE DIGITS . . . 000-00000-00-00

These "Middle Five Digits" indicate the type of part i.e., piston, rings, lower units, etc. The five digits are broken down as follows:



The "Major Classification" indicates the section to which the parts belong, i.e., engine, electrical etc. The "Intermediate" and "Minor Classifications" indicate more specific details.

Example:



DESIGN CODE NUMBER: 000-00000-00-00

The design code distinguishes like component parts from one another when specification differences are involved. For example, distinguishing a standard size piston ring from an oversized piston ring.

Example:

4BR-11610-0 0-00 Standard Piston Ring Set for XJ600SE
4BR-11610-2 0-00 Oversize Piston Ring Set for XJ600SE

DESIGN CHANGE CODE NUMBER: 000-00000-00-00

This code number is used to identify a difference between a new component part and old one when a new part is created by changing the old one.

Example: YFZ350E

2GU-11610-0 0-00 PISTON RING SET, STD. - ORIGINAL
2GU-11610-0 1-00 PISTON RING SET, STD. - FIRST DESIGN CHANGE


Only major changes to performance, durability, quality, appearance, cost or interchangeability will affect a part number change.

COLOR CODE & SIZE CODE NUMBER: 000-00000-00-00

When applicable, the last two digits of the part number identify:

1. Color Code: The painted color or type of plating or surface treatment used on certain parts.
2. Size Code: The last two digits are also used to show the size of parts (mm). Such as the thickness of shims or the size of pistons.

HARDWARE (Fastener) PART NUMBER CONFIGURATION:



TYPE:

A fastener part number always begins with the number "9" followed by either a 0, 1, 2, 3, 4, 5, 6, 7 or 8 designating one of eight major divisions within this group.

FOREWORD

Example:

- 9 0 000-00000-00 "0" designates various types.
- 9 1 000-00000-00 "1" designates bolts, cotter pins, etc.
- 9 2 000-00000-00 "2" designates screw, nuts, etc.
- 9 3 000-00000-00 "3" designates oil seals, o-rings, bearings, etc.
- 9 4 000-00000-00 "4" designates spark plugs.
- 9 5 000-00000-00 "5" designates bolts and nuts.
- 9 7 000-00000-00 "7" designates ISO bolts.
- 9 8 000-00000-00 "8" designates ISO screws and nuts.

The only major divisions which the mechanic should become familiar with are those related to the general hardware (nuts, bolts, and washers), since these are the most commonly used and most often replaced items. By knowing how to interpret the part number, the dimensions of a piece of hardware can be determined. This can be very helpful during major engine repair, and general parts replacement.

BOLT EXAMPLE:

91311 - 06 018 - 00
6mm outside diameter 18mm in length

EXCEPTION:

It is NOT possible to identify the LENGTH of bolts having a 901 prefix. Only the bolt diameter can be identified with this number.

NUT AND WASHER EXAMPLE:


95301 - 08600 - 00 NUT
8mm inside diameter

90201 - 25290 - 00 WASHER
25mm inside diameter


-MODEL LABEL-

A label called "Model Label" is affixed in the location as indicated in (3) below. When using this parts catalogue, please be sure to cross-reference the "model code - production code No." in the catalogue to the "model code - production code No." indicated on the Model Label affixed onto the product concerned.


"MODEL LABEL" INDICATION



- 1 Model Type Code
- 2 Production Code No
- 3 Coloring Type




MODEL LABEL AFFIXING LOCATION



MODEL CODE - PRODUCTION CODE NUMBER OF MODEL LISTED IN THIS PARTS CATALOG

Model Code	Production Code No.	Country (destination)
5FY5	010	U49
5FY6	010	CALIFORNIA

CYLINDER HEAD




Ref. No.	Part Number	Description	Qty	Remarks
1	15A-11110-03-00	CYLINDER HEAD ASSEMBLY .	1	
2	93440-10085-00	. CIRCLIP	2	
3	90153-06029-00	. SCREW, HEXAGON	1	
4	90430-06014-00	. GASKET	1	
5	5H0-11133-11-00	. GUIDE, INTAKE VALVE	2	
6	1NU-11181-00-00	GASKET, CYLINDER HEAD 1 .	1	
7	99530-14016-00	PIN, DOWEL	3	
8	90430-14131-00	GASKET	1	
9	90105-08195-00	BOLT, WASHER BASED	4	
10	90201-08609-00	WASHER, PLATE	4	
11	91317-08045-00	BOLT	2	
12	15A-11185-00-00	COVER, CYLINDER HEAD SIDE 1	1	
13	93211-05471-00	O-RING	1	
14	98507-06020-00	SCREW, PAN HEAD	2	
15	15A-11186-00-00	COVER, CYLINDER HEAD SIDE 2	1	
16	15A-11187-00-00	COVER, CYLINDER HEAD SIDE 3	1	
17	93210-57634-00	O-RING	2	
18	91317-06018-00	BOLT	5	
19	5H0-1111F-00-00	PLATE	1	
20	97007-06012-00	BOLT	2	
21	90215-06184-00	WASHER, LOCK	1	
22	NGK-D8EA0-00-00	PLUG, SPARK (NGK D8EA) ...	1	UR

FWD
3AWB110-2010

CYLINDER

Ref. No.	Part Number	Description	Qty	Remarks
1	21V-11310-00-00	CYLINDER	1	
2	93210-72529-00	O-RING	1	
3	4BD-11351-00-00	GASKET, CYLINDER	1	
4	93210-13361-00	O-RING	1	
5	99530-14016-00	PIN, DOWEL	2	
6	91317-06030-00	BOLT	2	
7	15A-11162-00-00	ABSORBER 2	2	
8	5H0-11162-00-00	ABSORBER 2	2	
9	15A-11161-01-00	ABSORBER 1	1	
10	15A-15441-00-00	HOLDER, CLUTCH CABLE ...	1	





54G100-6020

CRANKSHAFT - PISTON


Ref. No.	Part Number	Description	Qty	Remarks
1	5H0-11400-01-00	CRANKSHAFT ASSEMBLY ...	1	
2	5H0-11412-09-00	. CRANK 1	1	
3	5H0-11422-00-00	. CRANK 2	1	
4	5H0-11681-00-00	. PIN, CRANK 1	1	
5	93310-530J3-00	. BEARING	1	
6	15A-11651-00-00	. ROD, CONNECTING	1	
7	93306-30611-00	BEARING	1	
8	36X-11631-00-A0	PISTON (STD)	1	
	36X-11636-00-00	PISTON (0.50MM O/S)	1	
	36X-11638-00-00	PISTON (1.00MM O/S)	1	
9	15A-11603-00-00	PISTON RING SET (STD)	1	
	15A-11605-00-00	PISTON RING SET (0.50MM O/S)	1	
	15A-11607-00-00	PISTON RING SET (1.00MM O/S)	1	
10	15A-11633-00-00	PIN, PISTON	1	
11	93450-17044-00	CIRCLIP	2	
12	90201-201E4-00	WASHER, PLATE	1	
13	5H0-11496-00-00	BOSS, BUFFER	1	
14	90501-21133-00	SPRING, COMPRESSION	6	
15	93605-10090-00	PIN, DOWEL	3	
16	5H0-11536-00-00	GEAR, DRIVE (38T)	1	
17	90214-20023-00	WASHER, CLAW	1	
18	90240-07083-00	PIN, CLEVIS	1	
19	90501-07629-00	SPRING, COMPRESSION	1	
20	93602-13177-00	PIN, DOWEL	1	
21	5H0-11531-00-00	GEAR, BALANCE WEIGHT (38T)	1	
22	15A-11454-00-00	WEIGHT 1	1	
23	93306-30427-00	BEARING	1	

CONTINUED ON NEXT FRAME ➤



CRANKSHAFT - PISTON


Ref. No.	Part Number	Description	Qty	Remarks
24	93306-30427-00	BEARING	1	
25	90282-05013-00	KEY, STRAIGHT	1	
26	90215-14205-00	WASHER, LOCK	1	
27	90170-14284-00	NUT	1	
28	90280-05013-00	KEY, WOODRUFF	1	
29	90201-10508-00	WASHER, PLATE	1	
30	90101-10188-00	BOLT	1	



5FY5100-0030

VALVE


Ref. No.	Part Number	Description	Qty	Remarks
1	5H0-12111-01-00	VALVE, INTAKE	1	
2	5H0-12121-01-00	VALVE, EXHAUST	1	
3	4G0-12116-01-00	SEAT, VALVE SPRING	2	
4	11H-12113-00-00	SPRING, VALVE INNER	2	
5	11H-12114-00-00	SPRING, VALVE OUTER	2	
6	5H0-12119-00-00	SEAL, VALVE STEM	2	
7	4G0-12117-00-00	RETAINER, VALVE SPRING ..	2	
8	4G0-12118-00-00	COTTER, VALVE	4	
9	36X-12151-00-00	ARM, VALVE ROCKER	2	
10	5H0-12156-00-00	SHAFT, ROCKER 2	1	
11	5H0-12146-00-00	SHAFT, ROCKER	1	
12	93210-09165-00	O-RING	1	
13	2NX-12159-00-00	SCREW, VALVE ADJUSTING ..	2	
14	90170-06128-00	NUT	2	



5H0110-0040

CAMSHAFT - CHAIN


Ref. No.	Part Number	Description	Qty	Remarks
1	36X-12171-00-00	CAMSHAFT 1	1	
2	1KH-12176-00-00	SPROCKET, CAM CHAIN	1	
3	93604-10011-00	PIN, DOWEL	1	
4	90101-10303-00	BOLT	1	
5	90201-10591-00	WASHER, PLATE	1	
6	90387-255F3-00	COLLAR	1	
7	94580-41104-00	CHAIN	1	
8	5H0-12231-00-00	GUIDE, STOPPER 1	1	
9	5N0-12241-00-00	GUIDE, STOPPER 2	1	
10	25A-12217-00-00	ROD, CHAIN TENSIONER	1	
11	3Y1-12232-00-00	DAMPER	1	
12	90501-10587-00	SPRING, COMPRESSION	1	
13	90149-14182-00	SCREW	1	
14	90501-22721-00	SPRING, COMPRESSION	1	
15	90179-14298-00	NUT	1	
16	93210-16325-00	O-RING	2	
17	3Y1-12212-00-00	CASE, CHAIN TENSIONER ...	1	
18	97027-06016-00	BOLT	2	
19	92907-06600-00	WASHER, PLATE	2	




2JY110-7050

OIL PUMP


Ref. No.	Part Number	Description	Qty	Remarks
1	5H0-13300-02-00	OIL PUMP ASSEMBLY	1	
2	5H0-13326-01-00	. GEAR, PUMP DRIVEN 2 (45T)	1	
3	93603-12030-00	. PIN, DOWEL	1	
4	4BE-13329-00-00	GASKET, PUMP COVER	1	
5	98707-06030-00	SCREW, FLAT HEAD	3	
6	51Y-13411-00-00	STRAINER, OIL	1	
7	90501-18576-00	SPRING, COMPRESSION	1	
8	5H0-15351-00-00	PLUG, DRAIN	1	
9	93210-347A1-00	O-RING	1	
10	5H0-13440-00-00	ELEMENT ASSEMBLY, OIL CLEANER	1	
11	3AW-13447-00-00	COVER, OIL ELEMENT	1	
12	93210-54175-00	O-RING	1	
13	90109-06419-00	BOLT	1	
14	93210-07135-00	O-RING	1	
15	98507-06025-00	SCREW, PAN HEAD	1	
16	98507-06075-00	SCREW, PAN HEAD	1	



2JY110-7060

INTAKE

Ref. No.	Part Number	Description	Qty	Remarks
1	2JX-13586-00-00	JOINT, CARBURETOR 1	1	
2	93210-35537-00	O-RING	1	
3	91317-06020-00	BOLT	2	
4	1HX-13575-00-00	BAND	1	
5	2JX-14411-00-00	CASE, AIR CLEANER 1	1	
6	2JX-14453-00-00	JOINT, AIR CLEANER 1	1	
7	2JX-14437-00-00	DUCT	1	
8	2JX-14412-00-00	CAP, CLEANER CASE 1	1	
9	2JX-14452-00-00	SEAL	1	
10	97707-50520-00	SCREW, TAPPING	7	
11	2JX-14451-00-00	ELEMENT, AIR CLEANER	1	
12	2JX-14458-00-00	GUIDE	1	
13	2JX-14422-00-00	CAP, CLEANER CASE 2	1	
14	5U8-14457-00-00	SEAL	1	
15	90154-05005-00	SCREW, BINDING	4	
16	34X-1443E-00-00	PIPE, DRAIN	1	
17	90467-11106-00	CLIP	1	
18	90460-46206-00	CLAMP, HOSE	1	
19	90119-06056-00	BOLT, WITH WASHER	1	
20	90119-06063-00	BOLT, WITH WASHER	2	




2JY110-7070

CARBURETOR


Ref. No.	Part Number	Description	Qty	Remarks
1	2JX-14301-01-00	CARBURETOR ASSEMBLY 1	1	CA
	2JY-14301-02-00	CARBURETOR ASSEMBLY 1	1	49
2	30X-14198-00-00	. GASKET	1	
3	1LN-14291-00-00	. BRACKET 1	1	
4	30X-14105-00-00	. PILOT SCREW SET	1	
5	1KH-14153-00-00	. WASHER, MAIN JET	1	
6	98501-04016-00	. SCREW, PAN HEAD	2	
7	92901-04100-00	. WASHER, SPRING	2	
8	92901-04600-00	. WASHER, PLATE	2	
9	98580-04015-00	. SCREW, PAN HEAD	1	
10	92990-04100-00	. WASHER, SPRING	1	
11	43F-14342-20-00	. JET, PILOT (40)	1	
12	360-24512-00-00	. GASKET	1	
13	2JX-14341-00-00	. NOZZLE, MAIN	1	
14	288-14343-57-00	. JET, MAIN (114)	1	
15	2JN-14385-00-00	. FLOAT	1	
16	689-14386-00-00	. PIN, FLOAT	1	
17	2JX-14107-00-00	. NEEDLE VALVE SET	1	
18	30X-14384-00-00	. GASKET, FLOAT CHAMBER	1	
19	2JX-1490J-00-00	. NEEDLE SET	1	
20	2JX-14312-35-00	. VALVE, THROTTLE 1	1	
21	1WN-14197-00-00	. PIPE	2	CA
	54G-14348-01-00	. PIPE 1	1	49
22	3WP-14103-00-00	. THROTTLE SCREW SET	1	
23	5Y1-14216-00-00	. SCREW	1	
24	30X-14358-00-00	. NUT	1	
25	5Y1-14572-00-00	. PLATE, STAY	1	
26	51Y-14371-01-00	. PLUNGER, STARTER	1	
27	97801-04012-00	. SCREW, PAN HEAD	4	


CONTINUED ON NEXT FRAME ➤



CARBURETOR

Ref. No.	Part Number	Description	Qty	Remarks
28	92901-04100-00	. WASHER, SPRING	4	
29	14T-14323-00-00	. SCREW, AIR ADJUSTING ...	1	
30	5H0-14126-00-00	. GASKET	1	
31	5H0-14991-00-00	. SCREW	1	
32	5Y1-1490A-00-00	. DIAPHRAGM SET 1	1	
33	34K-14197-00-00	. PIPE	1	
	56R-14196-00-00	. PIPE	1	
34	5Y1-14197-00-00	. PIPE	1	
35	2JL-14149-00-00	. PIPE	1	
36	90413-05008-00	. WAY 3	1	
37	2JX-14396-00-00	. PIPE	1	
38	1JK-14197-00-00	. PIPE	1	49
39	5Y1-14118-00-00	. CAP	1	49
40	2JX-14193-00-00	PIPE	1	CA
41	2JX-14148-00-00	PIPE	1	CA
42	95807-08012-00	BOLT, FLANGE	1	CA
43	90464-20064-00	CLAMP	1	CA






2JY110-7090

EXHAUST

Ref. No.	Part Number	Description	Qty	Remarks
1	2JX-14611-01-00	PIPE, EXHAUST 1	1	
2	5H0-14612-00-00	NUT, RING	1	
3	54G-14628-01-00	PROTECTOR, EXHAUST PIPE .	1	
4	4BD-14766-00-00	WASHER, PROTECTOR	4	
5	98907-06010-00	SCREW, BIND	2	
6	90206-06090-00	WASHER, WAVE	2	
7	2JX-14711-00-00	MUFFLER 1	1	
8	2JX-14728-00-00	PROTECTOR, MUFFLER 2	1	
9	90202-05191-00	WASHER, PLATE	4	
10	98907-06010-00	SCREW, BIND	2	
11	90206-06090-00	WASHER, WAVE	2	
12	1RH-14752-01-00	PIPE, OUTLET	1	
13	98507-06010-00	SCREW, PAN HEAD	1	
14	92907-06600-00	WASHER, PLATE	1	
15	3YF-14714-00-00	GASKET, MUFFLER	1	
16	91317-08025-00	BOLT	1	
17	92907-08600-00	WASHER, PLATE	1	
18	22W-24181-00-00	DAMPER, LOCATING 1	1	
19	4BE-14613-00-00	GASKET, EXHAUST PIPE	1	
20	91317-06020-00	BOLT	2	
21	91317-08016-00	BOLT	1	
22	90201-08326-00	WASHER, PLATE	2	
23	95817-08016-00	BOLT, FLANGE	1	
24	90201-08326-00	WASHER, PLATE	1	


CRANKCASE

Ref. No.	Part Number	Description	Qty	Remarks
1	3AW-15100-02-00	CRANKCASE ASSEMBLY	1	
2	99530-12016-00	. PIN, DOWEL	2	
3	371-11167-01-00	. PIPE, BREATHER 2	1	
4	98507-06040-00	. SCREW, PAN HEAD	2	
5	90387-125F1-00	COLLAR	1	
6	90387-125F1-00	COLLAR	1	
7	98507-06030-00	SCREW, PAN HEAD	7	
8	98507-06090-00	SCREW, PAN HEAD	2	
9	98507-06085-00	SCREW, PAN HEAD	1	
10	90430-06014-00	GASKET	1	
11	3Y1-11166-00-00	PIPE, BREATHER 1	1	
12	90467-14015-00	CLIP	2	
13	90465-08200-00	CLAMP	1	
14	90462-06080-00	CLAMP	1	



CRANKCASE COVER 1

Ref. No.	Part Number	Description	Qty	Remarks
1	3AW-15410-00-00	CRANKCASE COVER ASSEMBLY 1	1	
2	2JX-15377-00-00	GUIDE, INLET	1	
3	3AW-15451-03-00	GASKET, CRANKCASE COVER 1	1	
4	99530-12016-00	PIN, DOWEL	2	
5	98507-06025-00	SCREW, PAN HEAD	8	
6	98507-06035-00	SCREW, PAN HEAD	2	
7	90340-14128-00	PLUG, STRAIGHT SCREW	1	
8	93210-14369-00	O-RING	1	
9	90340-32123-00	PLUG, STRAIGHT SCREW	1	
10	93210-32172-00	O-RING	1	
11	90465-08300-00	CLAMP	1	
12	98507-06010-00	SCREW, PAN HEAD	1	
13	90465-16187-00	CLAMP	1	
14	3AW-15431-01-00	COVER, CRANKCASE 3	1	
15	4BE-15462-00-00	GASKET, CRANKCASE COVER 3	1	
16	99530-12016-00	PIN, DOWEL	2	
17	98507-06025-00	SCREW, PAN HEAD	5	
18	98507-06035-00	SCREW, PAN HEAD	3	
19	98507-06045-00	SCREW, PAN HEAD	2	
20	3Y1-15363-00-00	PLUG, OIL	1	
21	93210-19123-00	O-RING	1	
22	3Y1-15361-00-00	GAUGE, LEVEL	1	




2YG110-8110

STARTER

Ref. No.	Part Number	Description	Qty	Remarks
1	15A-15660-01-00	KICK AXLE ASSEMBLY	1	
2	90468-26122-00	CLIP	1	
3	401-15676-00-00	COVER, SPRING	1	
4	15A-15666-00-00	SPACER	1	
5	90508-26538-00	SPRING, TORSION	1	
6	99009-17400-00	CIRCLIP	1	
7	90201-175F6-00	WASHER, PLATE	1	
8	36X-15641-00-00	GEAR, KICK	1	
9	90209-17226-00	WASHER	1	
10	93102-17263-00	OIL SEAL	1	
11	90201-173F4-00	WASHER, PLATE	1	
12	15A-15651-01-00	GEAR, KICK IDLE (28T)	1	
13	90214-17028-00	WASHER, CLAW	1	
14	99009-17400-00	CIRCLIP	2	
15	54G-15620-00-00	KICK CRANK ASSEMBLY	1	
16	54G-15621-00-00	. BOSS, KICK CRANK	1	
17	90501-12081-00	. SPRING, COMPRESSION	1	
18	93507-32009-00	. BALL	1	
19	90152-06010-00	. SCREW, COUNTERSUNK ...	1	
20	90338-18014-00	PLUG	1	
21	97027-08030-00	BOLT	1	
22	2HT-15512-00-00	GEAR, IDLER 1	1	
23	5H0-15521-00-00	SHAFT 1	1	
24	5H0-15517-00-00	GEAR, IDLER 2 (56T)	1	
25	90201-25290-00	WASHER, PLATE	1	
26	4H7-15580-10-00	STARTER CLUTCH OUTER ASSEMBLY	1	
27	90501-04596-00	. SPRING, COMPRESSION	3	
28	1J7-15583-01-00	. CAP, STARTER CLUTCH SPRING	3	


CONTINUED ON NEXT FRAME ➤




3AW7171-0120

STARTER

Ref. No.	Part Number	Description	Qty	Remarks
29	93615-12088-00	. PIN, DOWEL	3	
30	91317-08016-00	BOLT	3	




3AW7171-0120



3AWL110-5130

CLUTCH

Ref. No.	Part Number	Description	Qty	Remarks
1	5H0-16111-00-00	GEAR, PRIMARY DRIVE (22T)	1	
2	90282-05043-00	KEY, STRAIGHT	1	
3	90215-14205-00	WASHER, LOCK	1	
4	90170-14284-00	NUT	1	
5	15A-16150-00-00	PRIMARY DRIVEN GEAR COMP.73/ 7	1	
6	5H0-16154-00-00	PLATE, THRUST 1	1	
7	2JX-16371-00-00	BOSS, CLUTCH	1	
8	537-16321-00-00	PLATE, FRICTION	5	
9	137-16324-00-00	PLATE, CLUTCH 1	4	
10	5H0-16351-00-00	PLATE, PRESSURE 1	1	
11	90501-23700-00	SPRING, COMPRESSION	4	
12	90159-05011-00	SCREW, WITH WASHER	4	
13	1W1-16358-01-00	PLATE, PUSH	1	
14	2JX-16356-00-00	ROD, PUSH 1	1	
15	93210-48364-00	O-RING	1	
16	92907-06200-00	WASHER	1	
17	95307-06600-00	NUT	1	
18	90215-14186-00	WASHER, LOCK	1	
19	90170-14284-00	NUT	1	
20	15A-16380-00-00	PUSH LEVER ASSEMBLY	1	
21	90430-08119-00	GASKET	1	
22	90149-08067-00	SCREW	1	
23	90508-18537-00	SPRING, TORSION	1	
24	5H0-16357-00-00	ROD, PUSH 2	1	
25	93505-16006-00	BALL	1	
26	90386-14103-00	BUSH	1	
27	93102-14209-00	OIL SEAL	1	
28	93420-28055-00	CIRCLIP	1	




TRANSMISSION

Ref. No.	Part Number	Description	Qty	Remarks
1	15A-17411-01-00	AXLE, MAIN	1	
2	15A-17151-00-00	GEAR, 5TH PINION (28T)	1	
3	90209-16209-00	WASHER	1	
4	93410-20038-00	CIRCLIP	1	
5	5H0-17121-01-00	GEAR, 2ND PINION (22T)	1	
6	15A-17141-00-00	GEAR, 4TH PINION (25T)	1	
7	15A-17121-00-00	GEAR, 2ND PINION (19T)	1	
8	93306-20401-00	BEARING (B6204)	1	
9	93101-15101-00	OIL SEAL	1	
10	93306-20201-00	BEARING (B6202)	1	
11	2JX-17402-00-00	DRIVE AXLE ASSEMBLY	1	
12	15A-17221-00-00	GEAR, 2ND WHEEL (34T)	1	
13	15A-17241-00-00	GEAR, 4TH WHEEL (26T)	1	
14	15A-17231-00-00	GEAR, 3RD WHEEL (29T)	1	
15	15A-17251-00-00	GEAR, 5TH WHEEL (23T)	1	
16	90209-18208-00	WASHER	1	
17	93410-22039-00	CIRCLIP	1	
18	15A-17211-01-00	GEAR, 1ST WHEEL (34T)	1	
19	90201-17257-00	WASHER, PLATE	1	
20	99009-17400-00	CIRCLIP	1	
21	90201-220J8-00	WASHER, PLATE	1	
22	93306-20580-00	BEARING	1	
23	93102-22389-00	OIL SEAL	1	
24	93306-20332-00	BEARING	1	
25	93823-14149-00	SPROCKET, DRIVE (14T)	1	
26	2JX-17456-00-00	HOLDER, SPROCKET	1	
27	97007-05010-00	BOLT	2	
28	2JX-17471-00-00	PLATE, COVER	1	
29	98507-06010-00	SCREW, PAN HEAD	2	

CONTINUED ON NEXT FRAME ➤

TRANSMISSION


Ref. No.	Part Number	Description	Qty	Remarks
30	93102-17187-00	OIL SEAL	1	
31	93306-20313-00	BEARING (B6203C4)	1	



2JY110-7140

SHIFT CAM - FORK


Ref. No.	Part Number	Description	Qty	Remarks
1	5N0-18540-00-00	SHIFT CAM ASSEMBLY	1	
2	136-18542-00-00	. POINT, NEUTRAL	1	
3	93315-23607-00	BEARING	1	
4	1RH-18185-00-00	SEGMENT	1	
5	93604-16092-00	PIN, DOWEL	3	
6	93604-20156-00	PIN, DOWEL	1	
7	90151-06013-00	SCREW, COUNTERSUNK	1	
8	1RH-18140-00-00	STOPPER LEVER ASSEMBLY .	1	
9	90508-26539-00	SPRING, TORSION	1	
10	4JG-18511-00-00	FORK, SHIFT 1	1	
11	4JG-18512-01-00	FORK, SHIFT 2	1	
12	4JG-18513-00-00	FORK, SHIFT 3	1	
13	3GX-18531-00-00	BAR, SHIFT FORK GUIDE 1 ...	1	
14	3GX-18535-00-00	BAR, SHIFT FORK GUIDE 2 ...	1	




5N0010-0170

SHIFT SHAFT

Ref. No.	Part Number	Description	Qty	Remarks
1	5H0-18120-02-00	SHIFT LEVER ASSEMBLY	1	
2	90506-08227-00	. SPRING, TENSION	1	
3	90508-29540-00	SPRING, TORSION	1	
4	99001-10600-00	CIRCLIP	1	
5	90201-12588-00	WASHER, PLATE	2	
6	93608-50158-00	PIN, DOWEL	1	
7	93102-12106-00	OIL SEAL (SD 12-22-5 HS)	1	
8	1RL-18110-00-00	SHIFT PEDAL ASSEMBLY	1	
9	132-18113-01-00	COVER, SHIFT PEDAL	1	
10	97027-06020-00	BOLT	1	




25A310-3170



3AWP110-6170


FRAME

Ref. No.	Part Number	Description	Qty	Remarks
1	2YG-21110-00-35	FRAME COMP.	1	SL 49
	3AW-21110-00-35	FRAME COMP.	1	SL CA
2	95817-08065-00	BOLT, FLANGE	4	
3	1RL-21316-00-35	STAY, ENGINE 3	1	SL 49
	2JX-21316-00-35	STAY, ENGINE 3	1	SL CA
4	90185-08089-00	NUT, SELF-LOCKING	4	
5	90201-08366-00	WASHER, PLATE	4	
6	2JX-21315-00-00	STAY, ENGINE 2	1	
7	95817-08050-00	BOLT, FLANGE	1	
8	90185-08089-00	NUT, SELF-LOCKING	1	
9	90201-08366-00	WASHER, PLATE	1	
10	90105-08066-00	BOLT, WASHER BASED	2	
11	95817-08120-00	BOLT, FLANGE	1	
12	90185-08089-00	NUT, SELF-LOCKING	1	
13	90201-08366-00	WASHER, PLATE	1	
14	1RL-21337-00-00	CLAMP, CABLE	1	
15	90185-08055-00	NUT, SELF-LOCKING	1	
16	1RL-21471-00-35	PROTECTOR, ENGINE	1	SL
17	128-27114-00-00	STOPPER, MAIN STAND	2	
18	34L-21485-00-00	DAMPER, RUBBER 1	1	
19	4N0-27114-00-00	STOPPER, MAIN STAND	1	
20	97007-06016-00	BOLT	1	
21	92907-06600-00	WASHER, PLATE	1	
22	4R8-21308-00-00	HELMET HANGER ASSEMBLY	1	
23	90151-06038-00	SCREW, COUNTERSUNK	1	
24	2JX-21190-00-35	REAR FRAME COMP.	1	SL
25	95827-06012-00	BOLT, FLANGE	4	
26	90338-12081-00	PLUG	2	
27	2JX-28100-00-00	TOOL KIT	1	

CONTINUED ON NEXT FRAME ➤

FRAME


Ref. No.	Part Number	Description	Qty	Remarks
28	3TJ-82131-00-00	BAND, BATTERY	1	



3AWPI10-6170

FENDER


Ref. No.	Part Number	Description	Qty	Remarks
1	3AW-21511-20-00	FENDER, FRONT	1	
2	2JX-21512-00-00	BRACKET, FENDER	1	
3	90154-05004-00	SCREW, BINDING	4	
4	95607-05200-00	NUT, SELF-LOCKING	4	
5	1A8-21518-00-00	HOLDER, CABLE	1	
6	91317-06020-00	BOLT	4	
7	3AW-21611-20-00	FENDER, REAR	1	
8	90480-12053-00	GROMMET	2	
9	90119-06063-00	BOLT, WITH WASHER	4	
10	2JX-21685-00-00	BRACKET, LICENSE	1	
11	90119-06056-00	BOLT, WITH WASHER	2	
12	2JX-21641-00-00	BRACKET, REFLECTOR	1	
13	98507-05012-00	SCREW, PAN HEAD	2	
14	92907-05600-00	WASHER, PLATE	2	
15	4G0-21639-00-00	DAMPER 2	1	
16	2JX-21669-00-00	SEAL	1	
17	34X-21691-00-00	FLAP	1	
18	2JX-21651-00-00	COVER, REAR FENDER	1	
19	98907-06014-00	SCREW, BIND	3	
20	90387-06681-00	COLLAR	3	
21	99247-00080-00	EMBLEM, YAMAHA	1	



5FY5100-0180

SIDE COVER


Ref. No.	Part Number	Description	Qty	Remarks
1	3AW-21711-20-0X	COVER, SIDE 1	1	LGB
2	90154-05013-00	SCREW, BINDING	2	
3	3AW-21721-20-0X	COVER, SIDE 2	1	LGB
4	2JX-2177A-00-00	BOX	1	
5	90480-13197-00	GROMMET	2	
6	90119-06056-00	BOLT, WITH WASHER	2	
7	90480-01141-00	GROMMET	2	
8	5FY-2173E-00-00	GRAPHIC 1	1	
9	5FY-2173F-00-00	GRAPHIC 2	1	
10	5FY-2179N-10-00	PLATE, EPA 2 (CALIFORNIA) .	1	
	5FY-2179V-10-00	PLATE, EPA 1 (NON CALIFORNIA)	1	



5FY5100-0190

REAR ARM


Ref. No.	Part Number	Description	Qty	Remarks
1	2JX-22110-00-35	REAR ARM COMP.	1	SL
2	2JX-22123-00-00	BUSH 1	1	
3	2JX-22124-00-00	BUSH 2	1	
4	90386-18146-00	BUSH	2	
5	90380-18139-00	BUSH, SOLID	2	
6	93109-18020-00	OIL SEAL	2	
7	401-22128-01-00	SEAL, GUARD	2	
8	401-22127-00-00	SHIM	1	UN
9	2JX-22141-00-00	SHAFT, PIVOT	1	
10	90201-120E8-00	WASHER, PLATE	1	
11	90185-12134-00	NUT, SELF-LOCKING	1	
12	34X-22311-00-00	CASE, CHAIN	1	
13	90119-05059-00	BOLT, WITH WASHER	2	
14	34X-22151-01-00	SEAL, GUARD	1	
15	90209-06187-00	WASHER, SPECL SHAP	1	
16	90119-05062-00	BOLT, WITH WASHER	1	
17	38V-22199-00-00	SUPPORT, CHAIN	1	
18	90387-06737-00	COLLAR	2	
19	97007-06020-00	BOLT	2	
20	93700-06009-00	NIPPLE, GREASE	2	



FWD
5FY5100-0200

REAR SUSPENSION


Ref. No.	Part Number	Description	Qty	Remarks
1	3AW-22210-00-P0	SHOCK ABSORBER ASSEMBLY, REAR	1	LRY51
2	90380-12051-00	. BUSH, SOLID	2	
3	1M1-22216-00-00	. BUSH, REAR SHOCK ABSORBER	1	
4	90109-100E2-00	BOLT	1	
5	95617-10100-00	NUT, U	1	
6	90201-100E9-00	WASHER, PLATE	1	
7	90240-12075-00	PIN, CLEVIS	1	
8	90201-12175-00	WASHER, PLATE	1	
9	91401-30025-00	PIN, COTTER	1	
10	30X-22129-00-00	COVER, THRUST 2	2	




FWD
2JY110-7210

STEERING

Ref. No.	Part Number	Description	Qty	Remarks
1	156-23412-00-00	RACE, BALL 2	1	
2	93501-04011-00	BALL	19	
3	22F-23411-01-00	RACE, BALL 1	1	
4	22F-23412-01-00	RACE, BALL 2	1	
5	93503-16003-00	BALL	22	
6	122-23416-00-00	COVER, BALL RACE 2	1	
7	90179-25033-00	NUT	1	
8	90105-14102-00	BOLT, WASHER BASED	1	
9	3Y1-23319-00-00	HOLDER, CABLE 2	1	
10	95807-06012-00	BOLT, FLANGE	1	
11	2JX-23435-00-35	CROWN, HANDLE	1	SL
12	1E6-23441-10-35	HOLDER, HANDLE UPPER ...	2	SL
13	95824-08035-00	BOLT, FLANGE	4	
14	95027-08050-00	BOLT, FLANGE	2	
15	3R1-23317-00-00	HOLDER, CABLE	1	
16	2JX-23174-00-00	STAY, HEADLIGHT	1	
17	95807-06012-00	BOLT, FLANGE	1	
18	30X-23445-00-00	DAMPER	1	




5FY5110-0220



FRONT FORK

Ref. No.	Part Number	Description	Qty	Remarks
1	2JX-23102-00-00	FRONT FORK ASSEMBLY (L.H)	1	
2	2JX-23126-00-00	. TUBE, OUTER (LEFT)	1	
3	22W-23153-L0-00	.. RING, SNAP	1	
4	22W-23145-L0-00	.. OIL SEAL	1	
5	51Y-23125-00-00	.. METAL, SLIDE 1	1	
6	54G-23144-00-00	.. SEAL, DUST	1	
7	2JX-23110-00-00	. INNER TUBE COMP 1	1	
8	2JX-23170-00-00	. CYLINDER COMP., FRONT FORK	1	
9	39K-23173-00-00	. SPINDLE, TAPER	1	
10	2JX-23141-00-00	. SPRING, FRONT FORK	1	
11	2JN-23111-00-00	. BOLT, CAP	1	
12	3J2-23114-00-00	. O-RING	1	
13	22U-23118-01-00	. SPACER	1	
14	583-23142-M0-00	. SEAT, SPRING UPPER	1	
15	278-23181-50-00	. BOLT, HEXAGON SOCKET HEAD	1	
16	509-23158-L0-00	. GASKET	1	
17	2JX-23103-00-00	FRONT FORK ASSEMBLY (R.H)	1	
18	2JX-23136-00-00	. TUBE, OUTER (RIGHT)	1	
19	22W-23153-L0-00	.. RING, SNAP	1	
20	22W-23145-L0-00	.. OIL SEAL	1	
21	51Y-23125-00-00	.. METAL, SLIDE 1	1	
22	54G-23144-00-00	.. SEAL, DUST	1	
23	2JX-23110-00-00	. INNER TUBE COMP 1	1	
24	2JX-23170-00-00	. CYLINDER COMP., FRONT FORK	1	
25	39K-23173-00-00	. SPINDLE, TAPER	1	
26	2JX-23141-00-00	. SPRING, FRONT FORK	1	
27	2JN-23111-00-00	. BOLT, CAP	1	

CONTINUED ON NEXT FRAME ➤




FRONT FORK

Ref. No.	Part Number	Description	Qty	Remarks
28	3J2-23114-00-00	. O-RING	1	
29	22U-23118-01-00	. SPACER	1	
30	583-23142-M0-00	. SEAT, SPRING UPPER	1	
31	278-23181-50-00	. BOLT, HEXAGON SOCKET HEAD	1	
32	509-23158-L0-00	. GASKET	1	
33	2JX-23340-00-00	UNDER BRACKET COMP.	1	
34	156-23411-00-00	. RACE, BALL 1	1	
35	164-23462-00-00	. SEAL, STEERING	1	
36	2JX-23191-20-00	BOOT	2	FARAWAY BLUE
37	2K5-23192-00-00	BAND	2	
38	1W4-23194-L0-00	SCREW, BOOT BAND	2	
39	97321-08035-00	BOLT	4	
40	92901-08100-00	WASHER, SPRING	4	
41	5Y1-23317-00-00	HOLDER, CABLE	1	
42	20G-85110-00-00	REFLECTOR ASSEMBLY	2	
43	95707-05500-00	NUT, FLANGE	2	
44	2JX-85112-00-00	BRACKET, REFLECTOR 1	2	
45	95807-06008-00	BOLT, FLANGE	2	

FUEL TANK

Ref. No.	Part Number	Description	Qty	Remarks
1	2JX-Y2410-00-01	FUEL TANK COMP.	1	PWS1 CA
	2JY-Y2410-00-07	FUEL TANK COMP.	1	PWS1 49
2	5FY-24240-00-00	. GRAPHIC SET	1	
3	4L0-24181-00-00	DAMPER, LOCATING 1	2	
4	30X-24182-01-00	DAMPER, LOCATING 2	1	
5	30X-24183-01-00	DAMPER, LOCATING 3	1	
6	30X-24186-01-00	WASHER, SPECIAL	1	
7	30X-24187-00-00	WASHER, SPECIAL	1	
8	97007-06012-00	BOLT	1	
9	92907-06600-00	WASHER, PLATE	1	
10	48Y-24602-00-00	CAP ASSEMBLY	1	49
	56R-24602-00-00	CAP ASSEMBLY	1	CA
11	23F-24500-01-00	FUEL COCK ASSEMBLY 1 ...	1	
12	4X8-24512-00-00	. O-RING	1	
13	97801-03008-00	. SCREW, PAN HEAD	2	
14	3AJ-24523-00-00	. VALVE PACKING	1	
15	3AJ-24534-00-00	. SEAL, COCK	1	
16	90149-06011-00	SCREW	2	
17	90202-05193-00	WASHER, PLATE	2	
18	90445-10458-00	HOSE	1	
19	90467-09006-00	CLIP	2	
20	4BE-24170-00-00	CANISTER ASSEMBLY	1	CA
21	90480-15342-00	GROMMET	2	CA
22	90387-063G3-00	COLLAR	2	CA
23	97007-06025-00	BOLT	2	CA
24	92907-06600-00	WASHER, PLATE	2	
25	20K-24180-00-00	ROLL OVER VALVE ASSEMBLY	1	CA
26	93210-10166-00	O-RING	1	CA


CONTINUED ON NEXT FRAME ➤



5FY5100-0240


FUEL TANK

Ref. No.	Part Number	Description	Qty	Remarks
27	90445-10458-00	HOSE	1	CA
28	90445-106A3-00	HOSE	1	CA
29	91A21-07024-00	TUBE, FLEXIBLE	1	CA
30	90467-09006-00	CLIP	2	CA
31	90467-11106-00	CLIP	1	CA
32	341-26397-01-00	BAND	1	
33	2JX-24141-00-00	PROTECTOR, FUEL TANK ...	2	




SEAT

Ref. No.	Part Number	Description	Qty	Remarks
1	2JX-24770-60-00	SEMI-DOUBLE SEAT ASSEMBLY	1	
2	2JX-24731-60-00	. COVER, SEAT	1	
3	2JX-24734-60-00	. BAND, SEAT	1	
4	90201-06059-00	. WASHER, PLATE	2	
5	97007-06020-00	. BOLT	2	
6	92907-06100-00	. WASHER, SPRING	2	
7	18A-24723-00-00	. DAMPER, SEAT	1	
8	1L9-24741-A0-00	. PAD, SEAT	1	
9	90119-06063-00	BOLT, WITH WASHER	2	



2JY110-7250

FRONT WHEEL




2JY110-7260

Ref. No.	Part Number	Description	Qty	Remarks
1	2JX-25111-00-00	HUB, FRONT	1	
2	2JX-25117-00-00	SPACER, BEARING	1	
3	183-25315-00-00	FLANGE, SPACER	1	
4	93306-20205-00	BEARING (B6202)	1	
5	93102-20009-00	OIL SEAL, SD-TYPE	1	
6	93306-20203-00	BEARING (B6202RS)	1	
7	2JX-2511E-00-35	DRUM, BRAKE	1	SL
8	54G-25185-00-00	RING 1	1	
9	90179-08410-00	NUT	3	
10	3Y1-25121-01-35	PLATE, BRAKE SHOE	1	SL
11	93105-47007-00	OIL SEAL	1	
12	3LS-W2536-00-00	BRAKE SHOE SET	1	
13	90506-15260-00	SPRING, TENSION	2	
14	214-25135-00-00	GEAR, DRIVE	1	
15	214-25149-01-00	CLUTCH, METER	1	
16	90201-22283-00	WASHER, PLATE	2	
17	99009-22400-00	CIRCLIP	1	
18	214-25138-00-00	GEAR, METER	1	
19	90201-07076-00	WASHER, PLATE	1	
20	109-25136-00-00	BUSH	1	
21	93104-07003-00	OIL SEAL	1	
22	3Y6-25351-00-00	CAMSHAFT	1	
23	3Y1-25155-01-00	LEVER, CAMSHAFT 1	1	
24	90101-06278-00	BOLT	1	
25	95307-06600-00	NUT	1	
26	3Y6-2533A-01-00	PLATE, INDICATOR	1	
27	94425-18446-00	RIM (2.50-18)	1	
28	2JX-25104-00-00	SPOKE SET, FRONT	1	
29	94113-184R7-00	TIRE (66P 130/80-18 TW31 AM)	1	BRIDGESTONE

CONTINUED ON NEXT FRAME ➤

FRONT WHEEL


Ref. No.	Part Number	Description	Qty	Remarks
30	94213-18232-00	TUBE (MC130/80-18)	1	BRIDGESTONE
31	94340-18086-00	BAND, RIM (4.00-18)	1	BRIDGESTONE
32	2JX-25181-00-00	AXLE, WHEEL	1	
33	90387-15600-00	COLLAR	1	
34	322-25118-00-00	COVER, HUB DUST	1	
35	90171-14020-00	NUT, CASTLE	1	
36	91401-30030-00	PIN, COTTER	1	
37	90201-15785-00	WASHER, PLATE	1	



2JY110-7260

REAR WHEEL

Ref. No.	Part Number	Description	Qty	Remarks
1	2JX-25311-00-00	HUB, REAR	1	
2	90560-17305-00	SPACER	1	
3	152-25115-00-00	FLANGE, SPACER 1	1	
4	93306-20310-00	BEARING (B6203DU)	1	
5	93306-20316-00	BEARING (B6203)	2	
6	93102-25311-00	OIL SEAL (FPJ 25-44-8 TS) ...	1	
7	5V7-2511E-00-35	DRUM, BRAKE	1	SL
8	54G-25185-00-00	RING 1	1	
9	90179-08410-00	NUT	3	
10	2JX-25336-00-00	RING 2	1	
11	2JX-25321-02-35	PLATE, BRAKE SHOE	1	SL
12	2JL-W2536-10-00	BRAKE SHOE SET	1	
13	90506-15260-00	SPRING, TENSION	2	
14	3Y6-25351-00-00	CAMSHAFT	1	
15	2N3-25155-00-00	LEVER, CAMSHAFT 1	1	
16	90101-06278-00	BOLT	1	
17	95307-06600-00	NUT	1	
18	90387-171T1-00	COLLAR	1	
19	2JX-2533A-00-00	PLATE, INDICATOR	1	
20	94445-14479-00	RIM	1	
21	2JX-25304-00-00	SPOKE SET, REAR	1	
22	94118-145U2-00	TIRE (180/80-14M/C 78PTW32T/T) ..	1	BRIDGESTONE
23	94218-14251-00	TUBE (180/80-14 TR4)	1	BRIDGESTONE
24	94318-14149-00	BAND, RIM (4.50-14)	1	BRIDGESTONE
25	15A-25450-20-00	SPROCKET, DRIVEN (50T) ...	1	
26	90109-08618-00	BOLT	6	
27	90185-08089-00	NUT, SELF-LOCKING	6	
28	90215-08160-00	WASHER, LOCK	3	




5FY4100-9270

CONTINUED ON NEXT FRAME ➤

REAR WHEEL


Ref. No.	Part Number	Description	Qty	Remarks
29	90201-086P8-00	WASHER, PLATE	6	
30	156-25398-00-00	BALANCER, WHEEL	1	UN
31	90387-171T2-00	COLLAR	1	
32	36R-25367-00-00	COVER, HUB DUST	1	
33	3Y1-25388-01-00	PULLER, CHAIN 1	1	
34	3Y1-25389-00-00	PULLER, CHAIN 2	1	
35	2JX-25381-00-00	AXLE, WHEEL	1	
36	90171-16024-00	NUT, CASTLE	1	
37	91401-30030-00	PIN, COTTER	1	
38	94580-88122-00	CHAIN (DID 428HG-122L)	1	
39	94680-88001-00	. JOINT, CHAIN (DID 428HG) ..	1	



5FY4100-9270

STEERING HANDLE - CABLE

Ref. No.	Part Number	Description	Qty	Remarks
1	2JX-26111-00-00	HANDLEBAR	1	
2	1LX-26242-01-00	GRIP (RIGHT)	1	
3	3Y1-26243-01-00	TUBE, THROTTLE GUIDE	1	
4	3Y1-26249-00-00	RING, LEAF	1	
5	1LX-26241-01-00	GRIP (LEFT)	1	
6	2JX-26302-01-00	THROTTLE CABLE ASSEMBLY	1	
7	1RL-26335-00-00	CABLE, CLUTCH	1	
8	90123-08046-00	BOLT	1	
9	90179-08148-00	NUT	1	
10	2JX-26341-10-00	CABLE, BRAKE	1	
11	90123-08046-00	BOLT	1	
12	90179-08148-00	NUT	1	
13	3Y1-26290-10-00	BACK MIRROR ASSEMBLY (L.H)	1	
14	3Y1-26290-00-00	BACK MIRROR ASSEMBLY (R.H)	1	




Ref. No.	Part Number	Description	Qty	Remarks
1	2JX-27211-00-90	PEDAL, BRAKE	1	ZK
2	97007-06020-00	BOLT	1	
3	95307-06700-00	NUT	1	
4	2JX-27231-00-00	ROD, BRAKE	1	
5	90240-06076-00	PIN, CLEVIS	1	
6	92907-06200-00	WASHER	1	
7	91401-20012-00	PIN, COTTER	1	
8	90506-18289-00	SPRING, TENSION	1	
9	1M1-27244-00-00	COVER	1	
10	90501-10245-00	SPRING, COMPRESSION	1	
11	90249-12008-00	PIN	1	
12	90175-06013-00	NUT, WING	1	
13	2JX-27410-00-90	FRONT FOOTREST ASSEMBLY (LEFT)	1	ZK
14	90508-20023-00	. SPRING, TORSION	1	
15	91701-08038-00	. PIN, CLEVIS	1	
16	91401-25012-00	. PIN, COTTER	1	
17	95827-12025-00	BOLT, FLANGE	1	
18	15A-27420-01-90	FRONT FOOTREST ASSEMBLY (RIGHT)	1	ZK
19	90508-20023-00	. SPRING, TORSION	1	
20	91701-08038-00	. PIN, CLEVIS	1	
21	91401-25012-00	. PIN, COTTER	1	
22	92017-10035-00	BOLT, BUTTON HEAD	1	
23	92017-10020-00	BOLT, BUTTON HEAD	1	
24	2JX-27311-02-00	STAND, SIDE	1	
25	90506-29360-00	SPRING, TENSION	1	
26	5Y1-27315-00-00	LINK, SIDE STAND	1	
27	90109-10473-00	BOLT	1	

5FY4100-9290


STAND - FOOTREST

Ref. No.	Part Number	Description	Qty	Remarks
28	90185-10037-00	NUT, SELF-LOCKING	1	
29	2JX-27442-00-33	BRACKET 2	1	YB
30	26F-27432-00-33	BRACKET 1	1	YB
31	92017-08016-00	BOLT, BUTTON HEAD	4	
32	2JX-27437-00-00	WASHER, SPECIAL	1	
33	120-27433-00-00	COVER, REAR FOOTREST ...	2	
34	120-27431-00-00	FOOTREST, REAR 1	2	
35	90201-20279-00	WASHER, PLATE	2	
36	91701-06032-00	PIN, CLEVIS	2	
37	91401-20012-00	PIN, COTTER	2	



COWLING 1


Ref. No.	Part Number	Description	Qty	Remarks
1	3AW-28351-20-00	BODY, COWLING	1	
2	90480-12053-00	GROMMET	2	
3	90159-06060-00	SCREW, WITH WASHER	1	
4	99247-00100-00	EMBLEM, YAMAHA	1	



3AWW100-8300

GENERATOR


Ref. No.	Part Number	Description	Qty	Remarks
1	2YG-81410-M0-00	STATOR ASSEMBLY	1	
2	2YG-85580-M0-00	COIL, PULSER	1	
3	2YG-85550-01-00	ROTOR ASSEMBLY	1	
4	98507-05030-00	SCREW, PAN HEAD	3	
5	92907-05100-00	WASHER, SPRING	3	
6	98507-06020-00	SCREW, PAN HEAD	2	




2YG110-8311

STARTING MOTOR


Ref. No.	Part Number	Description	Qty	Remarks
1	3AW-81890-00-00	MOTOR ASSEMBLY	1	
2	50M-81801-M0-00	. BRUSH SET	1	
3	93210-25711-00	. O-RING	1	
4	93210-55669-00	. O-RING	2	
5	59V-81828-M0-00	. SCREW SET	2	
6	2JX-8183G-M0-00	CORD COMP.	1	
7	98507-05008-00	SCREW, PAN HEAD	1	
8	92907-05100-00	WASHER, SPRING	1	



5FY5100-0320

FLASHER LIGHT


Ref. No.	Part Number	Description	Qty	Remarks
1	1UF-83310-00-00	FRONT FLASHER LIGHT ASSEMBLY 1	1	
2	51L-83332-01-00	. LENS, FLASHER	1	
3	256-84714-61-00	. BULB (12V-27/8W)	1	
4	97707-40620-00	. SCREW, TAPPING	1	
5	1UF-83320-00-00	FRONT FLASHER LIGHT ASSEMBLY 2	1	
6	51L-83342-01-00	. LENS, FLASHER 2	1	
7	256-84714-61-00	. BULB (12V-27/8W)	1	
8	97707-40620-00	. SCREW, TAPPING	1	
9	1UF-83330-00-00	REAR FLASHER LIGHT ASSEMBLY 1	1	
10	51L-83342-00-00	. LENS, FLASHER 2	1	
11	256-83311-70-00	. BULB (12V-27W)	1	
12	97706-40620-00	. SCREW, TAPPING	1	
13	1UF-83340-00-00	FLASHER LIGHT ASSEMBLY 2	1	
14	51L-83332-00-00	. LENS, FLASHER	1	
15	256-83311-70-00	. BULB (12V-27W)	1	
16	97706-40620-00	. SCREW, TAPPING	1	
17	95307-12700-00	NUT	4	
18	10V-83365-00-00	CAP	2	
19	18G-83365-00-00	CAP	2	



2YG110-8330

METER


Ref. No.	Part Number	Description	Qty	Remarks
1	2JX-83510-B0-00	SPEEDOMETER ASSEMBLY ..	1	
2	2JX-83536-A0-00	. SOCKET, METER	1	
3	4R0-83517-00-00	. BULB (12V-3.4W T10)	1	
4	5EK-83568-00-00	PILOT BOX, UPPER	1	
5	5Y1-83513-00-00	DAMPER	1	
6	15A-83519-00-00	BRACKET, METER	1	
7	1M1-83526-00-00	DAMPER 2	2	
8	90201-05033-00	WASHER, PLATE	2	
9	437-83525-00-00	CLIP	2	
10	90164-04008-00	SCREW, TAPPING	2	
11	15A-83509-00-00	SOCKET CORD ASSEMBLY ..	1	
12	123-83516-21-00	BULB (12V-3.4W)	3	
13	95807-06040-00	BOLT, FLANGE	2	
14	3R9-83550-00-00	SPEEDOMETER CABLE ASSEMBLY	1	
15	102-25137-00-00	RING, STOP	1	
16	93210-14104-00	O-RING	1	



2JY110-7340

HEADLIGHT


Ref. No.	Part Number	Description	Qty	Remarks
1	47J-84115-00-00	RIM, HEADLIGHT	1	
2	2JX-84320-A0-00	LENS ASSEMBLY	1	
3	1ML-84314-00-XX	WIRE, STARTER (D:5MM, 1.7M)	1	LM HALOGEN
4	2F9-84375-00-00	SETTING PLATE, BULB	1	
5	2F9-84397-01-00	COVER, SOCKET	1	
6	43F-84131-00-00	SCREW, RIM ADJUSTER	2	
7	233-84127-60-00	WASHER, SPECIAL	2	
8	5G2-84332-60-00	SPRING, SCREW	2	
9	198-84334-60-00	NUT, ADJUSTING	2	
10	5G2-84324-A0-00	SPRING, REFLECTOR	1	
11	30X-84196-00-00	COVER, SOCKET	1	
12	10V-84198-00-00	CLIP, COVER FITTING	2	
13	97007-06025-00	BOLT	2	
14	90387-063E6-00	COLLAR	2	
15	90480-14023-00	GROMMET	2	




2JY110-7350

TAILLIGHT


Ref. No.	Part Number	Description	Qty	Remarks
1	1W9-84710-61-00	TAILLIGHT UNIT ASSEMBLY ..	1	
2	1M1-84523-60-00	. GASKET, LENS	1	
3	1M1-84521-60-00	. LENS, TAILLIGHT	1	
4	1M1-84524-60-00	. SCREW, LENS FITTING	2	
5	256-84714-61-00	. BULB (12V-27/8W)	1	
6	4L0-84753-00-00	DAMPER	1	
7	90209-08125-00	WASHER	2	
8	90109-06005-00	BOLT	2	
9	90201-083A0-00	WASHER, PLATE	2	
10	36A-84551-00-00	BRACKET, LICENCE	1	
11	95807-06016-00	BOLT, FLANGE	2	
12	90201-06557-00	WASHER, PLATE	2	
13	95607-06100-00	NUT, U	2	
14	3G1-85130-01-00	REAR REFLECTOR ASSEMBLY	1	
15	95707-05500-00	NUT, FLANGE	1	



3AWT100-7380

HANDLE SWITCH - LEVER


Ref. No.	Part Number	Description	Qty	Remarks
1	2JX-83973-01-00	SWITCH, HANDLE 3	1	
2	98506-05022-00	. SCREW, PAN HEAD	1	
3	98506-05030-00	. SCREW, PAN HEAD	1	
4	3Y6-82911-00-00	HOLDER, LEVER 1	1	
5	4GY-83912-00-00	LEVER 1	1	
6	90109-06799-00	BOLT	1	
7	95607-06100-00	NUT, U	1	
8	97007-06022-00	BOLT	1	
9	92907-06100-00	WASHER, SPRING	1	
10	2JX-83976-00-00	SWITCH, HANDLE 1	1	
11	98506-05035-00	. SCREW, PAN HEAD	1	
12	98506-05020-00	. SCREW, PAN HEAD	1	
13	361-82921-31-00	HOLDER, LEVER 2	1	
14	23X-83922-00-00	LEVER 2	1	
15	90109-06799-00	BOLT	1	
16	95607-06100-00	NUT, U	1	
17	97007-06022-00	BOLT	1	
18	92907-06100-00	WASHER, SPRING	1	
19	437-83936-01-00	BAND, SWITCH CORD	4	
20	5H0-83980-00-00	FRONT STOP SWITCH ASSEMBLY	1	
21	5H0-82917-00-00	SWITCH	1	



3AW3110-9370

ELECTRICAL 1

Ref. No.	Part Number	Description	Qty	Remarks
1	4KJ-82310-10-00	IGNITION COIL ASSY	1	
2	95027-06016-00	BOLT, FLANGE	2	
3	1UY-82370-20-00	PLUG CAP ASSY	1	
4	2YG-85540-10-00	C.D.I. UNIT ASSEMBLY	1	
5	34X-85546-00-00	BAND	1	
6	2YG-82590-10-00	WIRE HARNESS ASSEMBLY ..	1	
7	437-83936-11-00	BAND, SWITCH CORD	1	
8	25G-83936-01-00	BAND, SWITCH CORD	1	
9	437-83936-01-00	BAND, SWITCH CORD	1	
10	437-83936-01-00	BAND, SWITCH CORD	1	
11	3TB-83936-00-00	BAND, SWITCH CORD	1	
12	90465-13152-00	CLAMP	2	
13	437-83936-01-00	BAND, SWITCH CORD	1	
14	4KM-82540-00-00	NEUTRAL SWITCH ASSY	1	
15	90430-10148-00	GASKET	1	
16	47X-81960-A3-00	RECTIFIER & REGULATOR ASSEMBLY	1	
17	3AY-81940-00-00	STARTER RELAY ASSEMBLY .	1	
18	95707-06500-00	NUT, FLANGE	2	
19	1RL-81950-92-00	RELAY ASSEMBLY	1	
20	1JE-82110-61-00	BATTERY ASSEMBLY (GM7CZ-3D)	1	
21	51Y-82122-00-00	SEAT, BATTERY	1	
22	2JX-82103-00-00	TERMINAL 1	2	
23	90153-06032-00	SCREW, HEXAGON	2	
24	90445-082F3-00	HOSE	1	
25	18G-82131-00-00	BAND, BATTERY	1	
26	2JX-82115-00-00	WIRE, PLUS LEAD	1	
27	5H0-82116-00-00	WIRE, MINUS LEAD	1	



CONTINUED ON NEXT FRAME ►

Ref. No.	Part Number	Description	Qty	Remarks
-------------	----------------	-------------	-----	---------

